

# HingeMaster™

## HingeMaster solves the problem!

Here is the solution for adjustment of welded parallel hinges. Forget loose fixed tools that damage hinges and varnish.

Through a hand twist you lock the tool around the hinge and thereby get a completely smooth grip that facilitates adjustment of the hinge in all directions.

## THREE SIMPLE STEPS

---



### Mount

Place the gap around the welded door hinge



### Lock

Lock HingeMaster by turning the handle



### Adjust

Adjust the hinge in desired direction

---

## Art.no. ST1100

Complete HingeMaster adjustment tool.

